

Assembly Guide



INSTALLING THE BRACKETS



STEP 1 Lay out the contents for the Air Flow Brackets.



STEP 2 Insert an M6 lock washer and a flat washer on to each of the M6 screws.



STEP 3 Locate the two Rivnuts next to the rear C-Clamp on the lower stiffener plate of your Edge cap.



STEP 4 Align the two holes on the Air Flow Bracket with the Rivnuts and firmly install the screws with an M6 Allen Wrench.

INSTALLING THE BRACKETS



STEP 5 Repeat the process for the other Air Flow Bracket.



STEP 6 To use the brackets in Air Flow Mode, fold the Brackets out.



STEP 7 Lower the side door on to the brackets.



STEP 8 Firmly close the latches.

Note, your latches can be locked and unlocked in this position.

INSTALLING THE BRACKETS



STEP 9 Air Flow Mode is now engaged.



STEP 10 To disengage Air Flow Mode, simply fold the Air Flow Brackets back in.



STEP 11 Lower the side door, and close the latches.



STEP 12 Air Flow Mode is now disengaged.



**THANKS FOR YOUR PURCHASE. PLEASE LET US
KNOW IF YOU HAVE ANY QUESTIONS.**

[SMARTCAP.COM](https://smartcap.com)

[SUPPORT.NA@SMARTCAP.COM](mailto:support.na@smartcap.com) - NORTH AMERICA

[SUPPORT.SA@SMARTCAP.COM](mailto:support.sa@smartcap.com) - REST OF WORLD